

MASTERM23 - 23PC MST TERMINAL TOOL KIT

MASTERM23

23 Piece Universal Terminal Tool Kit

<p>1 Tube 5.50mm x 26.50mm</p> <p>BMW, Mercedes, Opel, VW/Audi</p> <p>95983-01</p>	<p>2 Tube 4.37mm x 23.00mm</p> <p>BMW, Jaguar, Mercedes, Porsche, SAAB, Seat, Skoda</p> <p>95983-02</p>	<p>3 Tube 3.27mm x 20.00mm</p> <p>BMW, Mercedes, Opel, Porsche, VW/Audi</p> <p>95983-03</p>	<p>4 Flat Twin Blade 1.60mm x 15.00mm</p> <p>Ford</p> <p>95983-04</p>	<p>5 Flat Twin Blade 1.55mm x 20.00mm</p> <p>BMW, Ford, Mercedes, Opel, Porsche, Seat, Skoda, VW/Audi</p> <p>95983-05</p>	<p>6 Flat Twin Blade 1.55mm x 20.00mm</p> <p>BMW, Ford, Jaguar, Mercedes, Opel, Porsche, SAAB, Seat, Skoda, VW/Audi</p> <p>95983-06</p>	<p>7 Flat Twin Blade 1.60mm x 20.00mm</p> <p>Mercedes</p> <p>95983-07</p>	<p>8 Flat Blade 1.80mm x 18.00mm</p> <p>Ford, Jaguar, Mercedes, Opel, Porsche, VW/Audi</p> <p>95983-08</p>
<p>9 Square Blade 1.50mm x 18.00mm</p> <p>Ford, Mercedes</p> <p>95983-09</p>	<p>10 Flat Blade 1.55mm x 18.00mm</p> <p>Mercedes</p> <p>95983-10</p>	<p>11 Flat Twin Blade 1.50mm x 05.50mm</p> <p>BMW, Ford, Jaguar, Mercedes, Opel, Porsche, SAAB, Seat, Skoda, VW/Audi</p> <p>95983-11</p>	<p>12 Flat Twin Blade 1.65mm x 23.00mm</p> <p>Opel, Renault, Skoda, VW/Audi</p> <p>95983-12</p>	<p>13 Flat Blade 3.00mm x 19.50mm</p> <p>Ford, Mercedes</p> <p>95983-13</p>	<p>14 Flat Blade, Notched 1.00 x 18.00mm</p> <p>Ford, Jaguar, Porsche</p> <p>95983-14</p>	<p>15 Flat Blade, V-Notch 1.00 x 24.00mm</p> <p>BMW, Ford, Jaguar, Mercedes, Porsche, VW/Audi</p> <p>95983-15</p>	<p>16 Flat Blade 1.80 x 18.00mm</p> <p>BMW, Ford, Jaguar, Mercedes, Opel, Porsche, VW/Audi</p> <p>95983-16</p>
<p>17 Twin Blade 1.60mm x 25.00mm</p> <p>BMW</p> <p>95983-17</p>	<p>18 Triple Flat Blade 1.00mm x 9.00mm</p> <p>Mercedes</p> <p>95983-18</p>	<p>19 Pin Blade 0.90mm x 19.00mm</p> <p>Chrysler, Fiat, Ford, Honda, Mazda, Mercedes, Mitsubishi, Opel, Porsche, Renault, Seat, Toyota, VW/Audi</p> <p>95983-19</p>	<p>20 Twin Flat Blade 1.60mm x 20.00mm</p> <p>Ford</p> <p>95983-20</p>	<p>21 Flat Blade 0.90mm x 15.00mm</p> <p>BMW, Ford, Jaguar, Mercedes, Opel, Porsche, SAAB, Seat, Skoda, VW/Audi</p> <p>95983-21</p>	<p>22 Pick Blade 1.00mm x 19.00mm</p> <p>Honda, Opel, Toyota, VW/Audi</p> <p>95983-22</p>	<p>23 Twin Flat Blade 0.90mm x 13.00mm</p> <p>Opel, VW/Audi</p> <p>95983-23</p>	

Item: MASTERM23

Description: 23PC MST TERMINAL TOOL KIT

Notes: FS prefix on all part #'s All are off by one # starts with 0 for #1.

Figure No	Part Number	Description	No. Reqd	Warranty Code
0	FS95983-01	#1 TUBE, 5.00MM X 20.5MM	1	K
1	FS95983-02	#2 TUBE, 4.37MM X 23.0MM	1	K
2	FS95983-03	#3 TUBE, 3.25MM X 20.0MM	1	K
3	FS95983-04	#5 FLAT TWIN BLADE,1.55 X 20.0	1	K
4	FS95983-05	#5 FLAT TWIN BLADE, 1.55X20.0M	1	K
5	FS95983-06	#6 FLAT TWIN BLADE, 1.55X17.0M	1	K
6	FS95983-07	#7 FLAT TWIN BLADE W/ANGLE TIP	1	K
7	FS95983-08	#8 FLAT BLADE 1.8X18.0	1	K
8	FS95983-09	#9 SQUARE BLADE, 1.0 X 18.0MM	1	K
9	FS95983-10	#10 FLAT BLADE, 1.15 X 18.0MM	1	K
10	FS95983-11	#11 FLAT TWIN BLADE, 1.6 X 65	1	K
11	FS95983-12	#12 FLAT TWIN W/ANGLE TIP 1.65	1	K
12	FS95983-13	#13 FLAT BLADE 3.0X18.5MM	1	K
13	FS95983-14	#14 FLAT BLADE W/NOTCH, 1.0X19	1	K
14	FS95983-15	#15 FLAT BLADE, U-NOTCH, 1X24	1	K
15	FS95983-16	#16 FLAT BLADE, 1.8X18.0MM	1	K
16	FS95983-17	#17 FLAT TWIN BLADE, 1.6 X 25	1	K
17	FS95983-18	#18 TRIPLE FLAT BLADE 1.0X9.0	1	K
18	FS95983-19	#19 PIN BLADE, 0.9 X 19.0MM	1	K
19	FS95983-20	#20 TERMINAL TOOL	1	K
20	FS95983-21	#21 FLAT TWIN BLADE, 0.9 X 15	1	K
21	FS95983-22	#22 PICK BLADE, 1.0 X 19.0MM	1	K
22	FS95983-23	#23 FLAT TWIN BLADE, 0.9 X 13	1	K