


AL22 - LUBRICATOR



Item: AL22

Description: LUBRICATOR

Notes: * Optional parts available for purchase to attach other air tool accessories. Only items identified by part numbers are available for purchase.

Figure No	Part Number	Description	No. Reqd	Warranty Code
1	*K7*	BODY	1	
2	K7RSAL2202	BOWL F/AL22	1	X
3	*K7-	SHATTERGUARD	1	
4	*K7-	FIXED RING	1	
5	K7RSAL2005	O-RING FOR AN AL20	1	X
6	*K7-	NUT	1	
7	*K7-	SPRING	1	
8	*K7-	BALL	1	
9	*K7-	PLUG	1	
10	*K7-	ADJUSTING SCREW	1	
11	*K7-+	FILL PLUG	1	
12	*K7-	INSIDE CUP	1	
13	*K7-	OUTSIDE CUP	1	
14	*K7-	O-RING	1	
15	*K7-	SCREW	1	
16	*K7-	TUBE	1	
17	*K7-	O-RING	1	
18	*K7-	O-RING	1	
19	*K7RSAL2011	O-RING	1	
20	*K7-	O-RING	1	
21	*K7-	BRACKET	1	
22	*K7-	SPACER	1	
23	*K7-	MOUNT	1	
24	*K7-	SCREW	1	
25	*K7-	SPRING	1	
26	*K7-	ADJUSTING RING	1	
27	*K7-	O-RING	1	
28	*K7-	O-RING	1	
29	*K7-	O-RING	1	
30	*K7*	SCREW (INCLUDED WITH #33)	1	
31	*K7*	NUT (INCLUDED WITH #33)	1	
32	*K7*	O-RING (INCLUDED WITH #33)	2	

33	*K7*RSAL2488	CONNECT ASSEMBLY (INCLUDES 30-31, 32(2), 33, 34)	1
34	*K7*	CONNECT LINK (INCLUDED WITH 33)	1