

BRS8HD - HD BEARING & SEAL DRIVER



Item: BRS8HD

Description: HD BEARING & SEAL DRIVER

Notes: BRS8HD was a K warranty but has been changed to an M warranty to encourage part replacement rather than sending the entire tool for warranty. If the entire tool needs to be replaced contact the Supplier at Ph: (712) 542-1938

Figure No	Part Number	Description	No. Reqd	Warranty Code
1	HW12830	WASHER F/BRS12 KIT	1	K
2	HW59520	FLANGE NUT	1	X
3	HW59530	EXT ASSY. FOR PBR594	1	K
4	HW59540	HANDLE FOR PBR594	1	K
5	HW61960	3-43/64 DRIVER F/BRS8HD	1	H
6	HW61920	4-13/16 DRIVER F/BRS8HD	1	H
7	HW61910	4-7/8 DRIVER F/BRS8HD	1	H
8	HW61940	5-25/32 DRIVER F/BRS8HD	1	H
9	HW61930	5-1/2 DRIVER F/BRS8HD	1	H
10	HW61950	6.0 DRIVER F/BRS8HD	1	H