

ITTK06-1 - PCM/TRANSMISSION HARNESS TOOL



Item: ITTK06-1

Description: PCM/TRANSMISSION HARNESS TOOL

Notes: N/A

Figure No	Part Number	Description	No. Reqd	Warranty Code
1	ITTK06-1	PCM/TRANSMISSION HARNESS TOOL	1	D