

ITTK06 - IMPORT TERMINAL TOOL KIT



Item: ITTK06

Description: IMPORT TERMINAL TOOL KIT

Notes: A=ITTK06-4 , B=ITTK06-1, C=ITTK06-6, D=ITTK06-3, E=ITTK06-5, F=ITTK06-2

Figure No	Part Number	Description	No. Reqd	Warranty Code
1	ITTK06-5	ABS ECU .55 PIN TOOL	1	D
2	ITTK06-1	PCM/TRANSMISSION HARNESS TOOL	1	D
3	ITTK06-2	TERMINAL BLOCK TOOL	1	D
4	ITTK06-3	UNDERHOOD SENSOR TOOL	1	D
5	ITTK06-4	SHEATHING RIPPING TOOL	1	D
7	ITTK06-6	ABS ECU .35 PIN TOOL	1	D