

50W COB Rechargeable Floodlight with Bluetooth Speaker

Multifunction floodlight with powerful bluetooth speakers

COB Floodlight

Featuring COB technology the light delivers a super bright flood output upto 4000 lumens

Light Output

Adjust the light intensity from 400 to 4000 lumens by simply press the button to change mode

	1ST PRESS	2ND PRESS	3RD PRESS	4TH PRESS
LUMEN	400	1000	2000	4000
RUN TIME	20 hours	10 hours	6 hours	3 hours

Powerful Bluetooth Speaker


Superior sound quality bluetooth speaker with range upto 10 meter (32') for endless music at work

For bluetooth connection of worklight to phone, press and hold the rectangle orange button for switching on the Bluetooth of the worklight and connect to "Audio Floodlight" from your phone.

Durable Construction


- IP65 Rated**
Protected against dust and effects of low pressure water jets from any direction
- Extremely tough & impact proof composite ABS body makes it suitable for all rugged applications
- Steel hook with 360° Rotating action for convenient placement of light

Power Source



RECHARGEABLE BATTERY
11.1V, 5200 mAh

Charging of Battery



AC CHARGER
(100-240V)

CHARGE TIME
3.5 HOURS

Charge Your Mobile Device

5V 1A USB output port for use as power bank



Hanging steel hook in base



Bluetooth* 4.0
Range: 10 M (32')
(Compatible with android and IOS)



140°
Vertical Rotation

MAX. LUMEN	WATER & DUST PROOF RATING	BLUETOOTH
4000	IP65	Bluetooth

SIZE (LxH xD)

(INCH)	(MM)
8-1/4 x 8-1/4 x 4"	210 x 210 x 100

SAFETY INFORMATION

- Follow workshop health & safety rules, regulations and conditions when using 50W COB Rechargeable Floodlight with Bluetooth Speaker.
- When not in use, COB rechargeable worklight should be stored in a dry location to inhibit rust.
- During their period of use, accessories must be checked for wear, cracks and other damage, replace any damaged or worn parts.
- Use genuine parts only. Unauthorized parts may be dangerous and will void the warranty.
- Keep the COB rechargeable worklight clean and in good working order for best and safest performance.
- DO NOT use the lamp in the immediate vicinity of inflammable materials or gases.
- DO NOT point the light directly in your own or any other person's or animal's eyes.
- DO NOT drop, throw or abuse the COB Rechargeable worklight.
- **Eyes protection:** Wear a protective mask or protective eyewear.
- Check that the product has not suffered any damage during transport or storage. Clean and remove any dust or residual packing material.
- Read the instructions carefully before using COB Rechargeable worklight and keep them for further reference.

WARNING!

- DO NOT immerse COB rechargeable worklight in water.
- DO NOT place COB rechargeable worklight near a fire or any other source of intense heat.
- DO NOT attempt to open, disassemble, modify or service the worklight.
- DO NOT expose COB rechargeable worklight to temperatures above 50°C (122° F).
- DO NOT use COB rechargeable worklight if you suspect that the batteries or the casing is damaged

PACKAGING CONTENT

DESCRIPTION	QTY.
COB Rechargeable Worklight	1
Power Cable with Adaptor	1
O.I.P.M.	1

OPERATING INSTALLATION

1. 5 LED indicators at the back shows the percentage charge in the worklight.



2. Fully charge the battery before the first use. To charge, connect the worklight with the charger cable provided with it. Connect the adaptor to the power source.
3. While charging, the 4 LED indicators at the back will blink continuously.
4. When the battery is fully charged, all the indicator LEDs will stop blinking. Full charging takes about 3.5 hours.
5. Press the power button located at the back of the light

BUTTON PRESS	LUMENS
1st Press	400
2nd Press	1000
3rd Press	2000
4th Press	4000

6. For bluetooth connection of worklight to phone, press and hold the orange button for switching on the Bluetooth of the worklight and connect to "Audio Floodlight" from your phone.
7. The worklight can also be used as power bank for charging mobile devices.



MAINTENANCE

- Clean any dirt from the housing or the lens immediately, since it could cause overheating.
- If required, clean with a dry or slightly moist clean cloth. Do not use cleaners that contain abrasives or solvents.
- When not in use, COB rechargeable worklight should be stored in a dry location.

TROUBLE SHOOTING

PROBLEM	POSSIBLE CAUSE	CORRECTIVE ACTION
The COB rechargeable worklight has low lumen output or does not work.	Low battery	Recharge the battery
The Bluetooth speaker does not work	Bluetooth out of Range	Worklight and the phone should be within 10 meter (33ft) range
If the COB rechargeable worklight still doesn't work		Contact nearest authorized service dealer

DISPOSAL

The components or the used products must be given to companies that specialize in the disposal and recycling of industrial waste.

