


MT2993 - QUICK LOCK 90 DIE GRINDER



Item: MT2993

Description: QUICK LOCK 90 DIE GRINDER

Notes: N/A

Figure No	Part Number	Description	No. Reqd	Warranty Code
1	*H1MT2993-01	HOUSING ASS?Y	1	
2	H1205QL-02	O-RING F/ MT2993	1	L
3	H1205QL-03	O-RING F/ MT2993	1	L
4	H1205QL-04	VALVE STEM F/ MT2993	1	L
5	H1205QL-05	SPRING F/MT2993	1	L
6	H1205QL-06	O-RING F/ MT2993	1	L
7	*H1205QL-07	VALVE PLUG	1	
8	*H1205QL-08	BALL BEARING	1	
9	*H1205QL-09	REAR END PLATE	1	
10	*H1205QL-10	DOWEL PIN	1	
11	*H1205QL-11	ROTOR	1	
12	*H1205QL-12	ROTOR BLADE	4	
13	*H1205QL-13	CYLINDER	1	
14	*H1205QL-14	BUSHING	1	
15	*H1205QL-15	PIN	1	
16	*H1205QL-16	FRONT END PLATE	1	
17	*H1205QL-17	BALL BEARING	2	
18	Q1205QL-18	GEAR ASSY F/ MT2993	1	L
19	*H1MT2993-19	MUFFLER COVER	1	
20	*H1205QL-20	EXHAUST DEFLECTOR	1	
21	H1205QL-21	AIR INLET BUSHING F/MT2993	1	L
22	*H1205QL-22	O-RING	1	
23	*H1205QL-23	EXHAUST HOOD	1	
24	*H1MT2993-24	HANDLE GRIP	1	
25	H1205QL-25	THROTTLE LEVER PIN F/ MT2993	1	L
26	H1205QL-26	THROTTLE LEVER F/ MT2993	1	L
27	*H1205QL-27	CONNECT NUT	1	
28	*H1205QL-28	SCREW	1	
29	*H1MT2993-29	PUSH BUTTON	1	
30	*H1205QL-30	SPRING	1	
31	*H1205QL-31	GEAR CASE ASS?Y	1	
32	*H1205QL-32	GREASE FITTING	1	
33	H1205QL-33	SPINDLE LOCK F/ MT2993	1	L

34	H1205QL-34	BEARING F/ MT2993	1	L
34	H1205QL-34	BEARING F/ MT2993	1	L
36	*H1205QL-36	KEY	1	
37	H1205QL-37	WORK SPINDLE	1	L
38	*H1205QL-38	WORK SPINDLE	1	
39	H1205QL-39	1/4 COLLET F/ MT2993	1	L
40	H1205QL-40	COLLETS NUT F/MT2993	1	L
41	*H1205QL-41	O-RING	1	
44	*H1205QL-44	O-RING	1	
45	H1205QL-45	WRENCH F/MT2993	1	L