


## MT3800 - 3/8" AIR RIVET NUT SETTING KIT



Item: MT3800

Description: 3/8" AIR RIVET NUT SETTING KIT

Notes: N/A

Figure No	Part Number	Description	No. Reqd	Warranty Code
0	*H1MT3800-10/24	10-24 MANDREL & NOSEPIECE (AVAIL. SEP)	1	
0	*H1MT3800-10/32	10-32 MANDREL & NOSEPIECE (AVAIL. SEP)	1	
0	*H1MT3800-8/32	8-32 MANDREL & NOSEPIECE (AVAIL. SEP)	1	
1	H1MT3800-01G	5/16 NOSEPIECE	1	D
1	*H1MT3800-01D	NOSEPIECE, M8	1	
1	*H1MT3800-01A	NOSEPIECE, M4	1	
1	*H1MT3800-01B	NOSEPIECE, M5	1	
1	*H1MT3800-01F	NOSEPIECE, 1/4	1	
1	*H1MT3800-01C	NOSEPIECE, M6	1	
1	*H1MT3800-01E	NOSEPIECE, M10	1	
1	*H1MT3800-01H	NOSEPIECE, 3/8	1	
2	H1MT3800-02	NOSE NUT F/ MT3800	1	L
3	*H1MT3800-03	STROKE ADAPTOR COVER	1	
4	*H1MT3800-04	CONNECTOR HOUSING	1	
5	*H1MT3800-05	JAW CASE, REAR	1	
6	*H1MT3800-06E	SCREW MANDREL (M10)	1	
6	*H1MT3800-06F	SCREW MANDREL (1/4)	1	
6	*H1MT3800-06H	SCREW MANDREL (3/8)	1	
6	*H1MT3800-06A	SCREW MANDREL (M4)	1	
6	*H1MT3800-06D	SCREW MANDREL (M8)	1	
6	*H1MT3800-06G	SCREW MANDREL (5/16)	1	
6	H1PRN1-10/24	10-24 MANDREL/NOSEPIECE ASSY	1	X
6	*H1MT3800-06B	SREW MANDREL (M5)	1	
6	*H1MT3800-06C	SCREW MANDREL (M6)	1	
6	H1PRN1-10/32	10-32 MANDREL/NOSEPIECE ASSY	1	X
6	H1PRN1-8/32	8-32 MANDREL/NOSEPIECE ASSY	1	X
7	*H1MT3800-07	SPINDLE GUIDE	1	
8	*H1MT3800-08	E RING	1	
9	*H1MT3800-09	RETURN TUBE	1	
10	*H1MT3800-10	LOCK NUT	1	
11	*H1MT3800-11	O RING	2	
12	*H1MT3800-12	BACKUP RING	1	
13	*H1MT3800-13	FRAME	1	

14	*H1MT3800-14	PISTON	1
15	*H1MT3800-15	O RING	1
16	*H1MT3800-16	BACKUP RING	1
17	*H1MT3800-17	PISTON RING	1
18	*H1MT3800-18	HANGING CLIP	1
19	*H1MT3800-19	O RING	1
20	*H1MT3800-20	FRAME CAP	1
21	*H1MT3800-21	SAFETY CAP NUT	1
22	*H1MT3800-22	O RING	2
23	*H1MT3800-23	BACKUP RING	1
24	*H1MT3800-24	CYLINDER	1
25	*H1MT3800-25	RUBBER CUSHION	1
26	*H1MT3800-26	LOCK NUT, FRAME	1
27	*H1MT3800-27	STEM, AIR PISTON	1
28	*H1MT3800-28	PLATE, LARGE	1
29	*H1MT3800-29	PISTON RING	1
30	*H1MT3800-30	WASHER	1
31	*H1MT3800-31	PLATE, SMALL	1
32	*H1MT3800-32	LOCK NUT, PISTON	1
33	*H1MT3800-33	O RING	1
34	*H1MT3800-34	CAP, CYLINDER	1
35	*H1MT3800-35	SPRING PIN	1
36	*H1MT3800-36	SPRING PIN	1
37	*H1MT3800-37	PUSHER, VALVE	1
38	*H1MT3800-38	SPRING, VALVE	1
39	*H1MT3800-39	COLLAR, VALVE	1
40	*H1MT3800-40	O RING	1
41	*H1MT3800-41	SPRING PIN	1
42	*H1MT3800-42	SPRING PIN	1
43	*H1MT3800-43	VALVE	1
44	*H1MT3800-44	SPRING, VALVE	1
45	*H1MT3800-45	O RING	1
46	*H1MT3800-46	CAP, VALVE	1
47	*H1MT3800-47	SPRING PIN	2
48	*H1MT3800-48	TRIGGER	1
49	*H1MT3800-49	TRIGGER ROD	1

50	*H1MT3800-50	TRIGGER LEVER	1	
51	*H1MT3800-51	SPANNER GAUGE	1	
52	*H1MT3800-52	SPANNER	1	
53	*H1MT3800-53	O RING	1	
54	H15706	BRASS AIR REGULATOR	1	X