

MINI TWIN HEAD WORK LIGHT

PLEASE READ CAREFULLY & FOLLOW DIRECTIONS BEFORE USE

BEFORE INITIAL USE - CHARGE BATTERY PACK FOR 4-8 HOURS

CHARGING INSTRUCTIONS:

- 1. Lift rubber cover on side of the light, insert Micro USB into light and insert USB end into USB power outlet (5V 1A).
- 2. Charging indicator will turn on, RED LED = charging in progress, GREEN LED = fully charged.
- 3. Remove Micro USB cable after fully charged and insert rubber cover into charging port.

OPERATING INSTRUCTIONS:

- 1. Push and release power button to cycle through high mode, low mode, and off.
- 2. Each light head can be independently adjusted to seven (7) angled positions.
- 3. Magnetic belt clip can be rotated 180°. Built-in hook and the magnet can be used for mounting.

REPLACEMENT COMPONENTS / ACCESSORIES:

FS60699 - Replacement Hook

FS99368 - USB Cord

FS99370 - USB Wall Adapter (Optional Accessory)

GENERAL GUIDELINES AND WARNINGS:

- Improper handling of the device may result in fire, personal injury, or property damage.
- Never charge device unattended. Do not charge on or near flammable material. Only charge using included USB cable or USB compliant cable.



- If device begins to balloon, swell, or smoke, discontinue using or charging immediately and observe
 device in a safe place.
- Do not short-circuit, crush, incinerate, or disassemble the device.
- Do not use if device or charging cable are damaged.
- . Do not dispose of batteries in trash. Always recycle batteries according to national or local regulations.
- The integrated battery should not be exposed to excessive heat such as sunshine, fire, etc.
- For optimal battery life, device should be operated and stored between 40°F 80°F

A WARNING: Cancer and Reproductive Harm. www.P65Warnings.ca.gov

The Mini Twin Head Work Light is backed by a 1 Year Warranty. This warranty covers manufacturer defects and workmanship. The warranty excludes misuse or abuse and normal wear and tear. Exclusion is not allowed in some states and may not apply. This warranty gives you specific legal rights, and you may have other rights, which vary from state to state.



AD CAREF JSE

BEFORE FO TIA 1-8 HC

CHARGING STF TIONS:

- 1. Lift JSB d into side of t liah ve. nse se **USB** 5V 1A).
- 2. Charging indicator will turn on, RED LED = charging in progress, GREEN LED = fully charged.
- 3. Remove Micro USB cable after fully charged and insert rubber cover into charging port.

OPERATING INSTRUCTION

- 1. Push and release power bu n to cycle igł ode w mode, and off.
- (7)2. Each light head can be inde led positions. tly a
- ed 180°. d the 3. Magnetic belt clip can be re ilt-in hook agnet can be used for mounting.

REPLACEMENT COMPONE ORIES: B / ACC

FS60699 - Replacement Hoo


FS99368 - USB Cord

FS99370 - USB Wall Adapter (Optional Accessory)

GENERAL GUIDELINES AND WARNINGS:



Improper handling of the device may result in fire, personal injury, or property damage.
 Never charge device unattended. Do not charge on or near flammable material. Only charge using included USB cable or USB compliant cable.




device in a stie p

• Do not short-cit u , cru mbl evice

The integrated battery should not be exposed to excessive heat such as sunshine, fire, etc.

For optimal battery life, device should be operated and stored between 40°F - 80°F

GENERAL GUIDELINES AND WARNINGS:





included USB cable

• If device begins to ıb!)k alloc i, . L.S on nue sing g immediately and observe device in a safe pla

• Do not short-circuit crus devi

Do not use if device or charging cable are uamaged.
 Do not dispose of batteries in trash. Always recycle batteries according to national or local regulations.

The integrated battery should not be exposed to excessive heat such as sunshine, fire, etc.

For optimal battery life, device should be operated and stored between 40°F - 80°F

ADVERTENCIA: Cáncer y daño reproductivo. www.P65Warnings.ca.gov

AVERTISSEMENT : Cancer et dommages à l'appareil reproducteur. www.P65Warnings.ca.gov

es D (a) cambiables, está respaldada por una Garantía de un año. Esta garantía cubre mano de bra. Esta garantía excluye el mal uso, abuso, uso normal y desgaste. Algunos Estados no permiten la exclusión o limitación de daños especiales, por lo que las exclusiones anteriores pueden no aplicar a su caso. Esta Garantía le otorga derechos específicos y el comprador puede tener otros derechos, dependiendo de su lugar de residencia.