## 10W COB Rechargeable Worklight

# Multi-function, powerful worklight & top torch

## **COB Worklight**

Worklight delivers extremely high output with uniform and even illumination

Top Torch is powered by 3W LED

#### **Light Output**

High quality output, both as a worklight & top torch

User controlled output: Adjust light intensity of worklight and top torch by pressing ON/OFF buttons continuously

## **Durable Construction**

Impact proof & water resistant ABS body with rubber coating.

## **Hands Free Operation**

## **Charge Time**

3.5 hours (indicated via LED display). LED Charging shown with display in percentage





WATER & DUST PROOF RATING	BEAM ANGLE	BEAM DISTANCE	OPERATING TEMPERATURE
IP44	270°	40m	-10°C TO +50°C (14°F TO 122°F)





180°Swivelling Magnetic Stand

Mounted on tripod

## **Working Mode**

Working Flode					
	1ST PRESS 2ND PRESS 3RD PRESS		3RD PRESS	4TH PRESS	
	TOP TORCH	WORKLIGHT	CONTINUOUS RED LIGHT	RED QUICK FLASHING	
LUMEN	150	500		0000000	
RUN TIME	4 hrs	3 hrs			

#### **SPECIFICATIONS**

LIGHT	10W COB Worklight & 3W LED Top Torch
LUMEN OUTPUT (WORKLIGHT / TOP TORCH)	500/150 lumen
OPERATING TIME (WORKLIGHT / TOP TORCH)	3/4 hours
MATERIAL	ABS, PC, TPR, Aluminum
DIMENSION	6-21/32 × 1-47/64 × 1-11/32 inch (169 × 44 × 34 mm)
WEIGHT	200 gm

#### **SAFETY INFORMATION**

- Follow workshop health & safety rules, regulations and conditions when using the 10W COB Rechargeable worklight.
- When not in use, COB rechargeable worklight should be stored in a dry location to inhibit rust.
- During their period of use, accessories must be checked for wear, cracks and other damage, replace any damaged or worn parts.
- Keep the COB rechargeable worklight clean and in good working order for best and safest performance.
- Eye protection: Wear a protective mask or protective eyewear.
- Check that the product has not suffered any damage during transport or storage. Clean and remove any dust or residual packing material.
- Read the instructions carefully before using COB Rechargeable worklight and keep them for further reference.

#### WARNING!

- DO NOT immerse COB rechargeable worklight in water
- DO NOT place COB rechargeable worklight near a fire or any other source of intense heat.
- DO NOT attempt to open, disassemble, modify or service the worklight.
- DO NOT expose rechargeable COB rechargeable worklight to temperatures above 50°C (122° F).
- DO NOT use COB rechargeable worklight if you suspect that the batteries or the casing is damaged
- DO NOT use the lamp in the immediate vicinity of inflammable materials or gases.
- DO NOT point the light directly in your own or any other person's or animal's eyes.
- DO NOT drop, throw or abuse the COB Rechargeable worklight.

## PACKAGE CONTENT

DESCRIPTION	QUANTITY
COB Rechargeable Worklight	1
Micro USB cable	1
O.I.P.M.	1

#### **OPERATING INSTRUCTIONS**

- Fully charge the battery before the first use. To charge, connect the worklight with the micro USB charger cable provided with it.
- 2. While charging, the green light will blink continuously on the LED display.
- 3. When the battery is fully charged, all the indicator LEDs will turn green. Full charging takes about 3.5 hours.
- 4. LED Screen at the back shows the percentage charge in the worklight.



- 5. Press the power button located at the back of the light
  - Once for Top Torch "ON"
  - Twice for Worklight "ON"
  - · Three times for continuous red light "ON"
  - Four times for red quick flashing "ON"
- Five times for switching "OFF" the light
- 6. Intensity of all four modes of light can be controlled by long press of the power button.
- 7. The worklight can also be used as power bank for charging mobile devices



## MAINTENANCE

- Clean any dirt from the housing or the lens immediately, since it could cause overheating.
- If required, clean with a dry or slightly moist, clean cloth and a mild detergent. Do not use cleaners that contain abrasives or solvents.
- When not in use, COB rechargeable worklight should be stored in a dry location.

## **TROUBLESHOOTING**

PROBLEM	POSSIBLE CAUSE	CORRECTIVE ACTION
The COB rechargeable worklight has low lumen output or does not work.	Low battery	Recharge the battery
If the COB rechargeable worklight still doesn't work		Contact nearest authorized service dealer

## **DISPOSAL**

The components or the used products must be given to companies that specialize in the disposal and recycling of industrial waste.