



# OWNER'S MANUAL

## Model No. CRHDTR

### Save This Manual For Future Reference

## HEAVY DUTY TRUCK CREEPER

### DESCRIPTION

Heavy-Duty Creeper with 5" Wheels has 1" diameter welded steel tube frame. Frame is 20" wide and 44" long. Upholstered vinyl fabric over 2" foam bed and headrest. Six 5" high-impact, non-marking, oil-resistant casters withstand harsh environments. Creeper has comfortable pillow style headrest. 500 pound load capacity with 3¼" ground clearance.

### ASSEMBLY INSTRUCTIONS

**Read these instructions before starting; follow assembly procedures carefully.**

1. To install casters (Key No. 4) onto frame (Key No. 1), place creeper on a workbench.
2. Insert stem portion of caster into one of the six holes in bottom of frame. Make sure stem portion of caster fits completely into frame. It may be necessary to use a punch and hammer to tap caster into frame.
3. Repeat process for five remaining casters. Make sure all six casters are properly seated into holes in bottom of frame.
4. Place headrest (Key No. 3) under frame with thickest part of headrest towards top of frame. Align T-nuts in headrest with four holes in frame.
5. Slide flat washer (Key No. 6) over pan head screw (Key No. 5) and secure headrest to frame. Secure three remaining screws with washers to headrest and tighten securely.

### GENERAL SAFETY INSTRUCTIONS

- Do not stand on creeper.
- Do not use this creeper as a stool or bench.
- Only use creeper when fully assembled.
- Periodically check fasteners and tighten securely if needed.
- Never use creeper if it does not perform according to this manual.
- Do not exceed creeper maximum weight capacity of 500 pounds.

### INDUSTRIAL SEATING LIMITED WARRANTY

Product is warranted against mechanical or structural failure due to defective material or workmanship for 1 year. Provided however, this warranty lasts only so long as you own your product. If you sell or otherwise transfer the product this warranty terminates automatically. Products that are damaged or made unserviceable by accidents, abuse, misuse or are altered in anyway are not covered by this warranty.

Matco Tools reserves the right to replace or recondition at its option, any units covered by this warranty. All return shipments require Material Return Authorization and must be freight prepaid unless otherwise approved in writing.

If any product covered under this warranty fails to meet the terms of this warranty or it is in any respect broken, defective or missing parts, please call us immediately at toll free 1-866-289-8665. Any attempts to make unauthorized repairs will void this warranty in every respect.

This warranty gives you specific legal rights. You may have other rights which vary from state to state, however such implied rights are limited to a period of one year from the date of your initial purchase. Some states do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you.


Matco Tools will in no event be liable for incidental or consequential damages for any amount in excess of the original purchase price. Some states do not allow exclusion or limitation of such damages, so the above limitation or exclusion may not apply to you.

### HOW TO ORDER REPAIR PARTS

When ordering repair parts or reporting problems, always give the following information:

NAME OF ITEM	MODEL NUMBER
Heavy Duty Truck Creeper	CRHDTR
PART DESCRIPTION	PART NUMBER
_____	_____

All parts listed may be ordered from Matco Tools® Customer Service at 1-866-289-8665.



**PARTS LIST**

KEY NO.	DESCRIPTION	QTY.	PART NO.
1	Frame	1	10414.01
2	Bed	1	10659.04
3	Headrest	1	10416.01
4	Caster	6	10660.00
5	1/4"-20 x 1 1/4" Phillips Pan Head Screw	4	07934.01
6	1/4" Flat Washer	12	10421.01
7	1/4"-20 x 1 1/2" Phillips Pan Head Screw	8	10412.00
8	Cap	4	10424.00