| STEEL | MAN® |
|-------|------|
|-------|------|



| $\mathbf{\Theta}$ |
|-------------------|
|                   |
|                   |
|                   |
|                   |
|                   |
| $\geq$            |
|                   |
| T2 -              |
|                   |
|                   |
|                   |
|                   |
| _                 |
|                   |
|                   |
|                   |
| U)                |
|                   |
| 2                 |
|                   |
|                   |
|                   |
| 4                 |
|                   |
| 02                |
|                   |
|                   |
|                   |
|                   |
| $\mathbf{O}$      |
| ЪЕ                |

| SPECIFICATIONS |                             |  |  |
|----------------|-----------------------------|--|--|
| PART NO.       | DESCRIPTION                 |  |  |
| 65001 ADVA     | NCED ELECTRONIC STETHOSCOPE |  |  |

# How to Use:

1) Install 9-volt battery in EngineEAR<sup>®</sup> control unit and attach headphone plug.

2) Turn On/Off switch to "Off" position before putting on headphones. Place headphones firmly over ears, then turn the switch to "On". Slowly increase volume to desired setting.

**EngineEAR**<sup>®</sup>

3) Place sensing tip flush on housing surface of suspect problem parts. By keeping the sensing tip flush against the suspect part, outside noises are blocked. Use the metal probe when working on hot or difficult to reach areas.

4) Use EngineEAR<sup>®</sup> to detect bad bearings and bushings, exhaust leaks, bad plug wires, wind and water leaks, noisy valves and lifters or a squeak or rattle under the dash.

## NOTE:

This device electronically amplifies sound and will provide clear sound around most automobile parts. Static interference will occasionally occur around the coil and distributor of most cars.

| KIT CONTENTS      |     |          |  |
|-------------------|-----|----------|--|
| Description       | QTY | Part No. |  |
| Control Unit      | 1   | 411      |  |
| Headphones        | 1   | HD-6060N |  |
| Rubber Sensor Tip | 1   | 65012    |  |
| Metal Probe       | 1   | 413      |  |

### **CAUTION:** It is against many state laws to operate a motor vehicle while wearing headphones.

#### LIMITED WARRANTY

**STEELMAN**<sup>®</sup> JS Products, Inc. has carefully examined each product at the time of manufacturing and warrants workmanship at the time of shipment. This warranty applies only to the original consumer/purchaser and is not valid if the product is misused, or if accidental damages occur. **STEELMAN**<sup>®</sup> JS Products, Inc. assumes no direct or indirect liability for incidental or consequential damages resulting from the use of its products. This warranty commences on the date of the original consumer purchase, and extends for 90 Days thereafter.

In the event of a defect or malfunction of a product, wherein repair or replacement should be necessary, call the Customer Service Department at 1-800-255-7011 for complete instructions on how to return the product for warranty repair or replacement. The original consumer/purchaser must provide a copy of the Bill of Sale or Invoice showing the date on which the purchase was made. After the (ninety) 90 Day Period, **STEELMAN**<sup>®</sup> JS Products, Inc. will charge a service charge for all parts and labor. Inbound and outbound freight will be paid by the consumer/purchaser.

Some states do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you. Additionally, some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation may not apply to you.

This warranty gives specific legal rights, and there may be other rights which vary from state to state.

# STEELMAN.

JS Products, Inc. • 5440 S. Procyon St. • Las Vegas, NV 89118 Phone: 702-362-7011 • Fax: 775-898-8773 • www.steelmantools.com